



HANDLING INSTRUCTION

opticalCON | FOPS-SINGLE Pulling Sock

PREPARATION



- Ⓐ Open metal zipper and attach the strain relief on the cable as illustrated on pic A.

Attention: Make sure that the strain relief is between the two velcro straps.



- Ⓑ Due to the strain relief is the center element for the pulling force, it's important to tighten the cable tie.



- Ⓒ With tighten the velcro straps, fix the attached strain relief and cable on the opticalCON pulling sock.



- Ⓓ Close metal zipper and tighten velcro strap to enhance cable retention of the entire pulling sock.

FINISH





STORAGE

A



- A Reel cable with attached pulling sock flat on the used cable drum.

B



- B Secure opticalCON pulling sock with the black hook on the metal grommet.

NOTE:



The proper length of the elastic cord can be individual adjusted according to the outer diameter of the used drum.

FINISH

